

5351-5361
Caremor Cliner

CUSTOMER INSTRUCTIONS



*If you have trouble understanding these instructions contact your dealer or Winco customer support, (800) 237-3377
PLEASE READ AND FAMILIARIZE YOURSELF WITH ALL INSTRUCTIONS BEFORE USING THIS PRODUCT.
before attempting to use this product; otherwise injury may occur.*

Winco assumes no responsibility for damage or injury caused by improper assembly, installation, use, or maintenance of these products.



1. READ AND FOLLOW ALL DIRECTIONS.
2. NEVER use tray as a restraint.
3. ALWAYS fold footplate up before user enters or exits the chair; otherwise INJURY MAY RESULT.
4. DO NOT stand on plastic footplate; INJURY MAY RESULT.
5. Keep users hands and feet clear of any moving parts. Attendant MUST confirm that users hands and feet are clear of moving parts before and while adjusting positions on tray or footrest or INJURY MAY RESULT.
6. Never use the chair arms or tray as a seat; INJURY MAY OCCUR.
7. Lock casters at all times, except when transporting chair.
8. Chair must ALWAYS be positioned on a level surface.
9. DO NOT use chair for Transporting in or with ANY type of vehicle or trailer. Winco chairs have not been tested or approved for use by an occupant in any type of vehicle or trailer.
10. Immediately remove from service; Any chair with broken parts, torn upholstery, or other mechanical or visible damage.
11. Periodically, recheck tightness of all nuts, bolts and screws.
12. USE ONLY WINCO AUTHORIZED REPLACEMENT PARTS.
13. NEVER EXCEED the recommended **weight capacity of 300 lbs.** (136 kg).
14. SAVE THESE INSTRUCTIONS for future reference and training.

5351-5361 Weight Capacity = 300 lbs. (136 kg.)

No Tools required for standard assembly.

PLEASE READ AND FAMILIARIZE YOURSELF WITH ALL INSTRUCTIONS BEFORE PROCEEDING WITH ASSEMBLY

Install the Back

1. After checking your product for any shipping damage, put chair in upright position.
2. Slide the **Back Frame** over the **7/8" tubes** of the **Seat Frame**. (FIG.3)
3. Depress the **1/4" Lock Button** in **Seat Frame** while pushing down on one side of **Back Frame**.
4. Repeat procedure on opposite side until both **Lock Buttons** are snapped into corresponding holes of **Back Frame**. **NOTE: Snap buttons must protrude out of holes on back frame.** (FIG.4)

WARNING: Failure to lock back and seat frames together may cause injury.

5. **Remove the wood spacing block from back frame after chair assembly.**
6. Press the “Hook & Loop” pieces together on bottom of chair back, to complete assembly and give finished look to back of chair.

Operation of the Tray – 5351 Only

7. The **Tray** automatically locks into the first position; depress the **Latch Button** for 2 more positions.
8. The **Right Tray Arm** is movable to compensate for minor variations in the width of the chair.
9. Storing the **Tray**; Insert the left tray arm tube into the right tray receiving tube and the **Latch Button** will lock it into place. Allow the right side of the table to hang down vertically on the right side of chair (Left & Right; as if you are seated in chair).
10. To make the tray permanently non-locking, remove the **Snap Button** of the **Right Tray Arm**.

Operation of the Chair

There are two ways to operate this chair; Attendant Controlled & User Controlled.

11. The chair comes from the factory set up for Attendant Controlled positioning of the chair. This means the Release Handle must be actuated by an attendant before positioning of the chair can be changed. By squeezing the Release Handle – moving the chair to the desired position – and releasing the handle - the attendant can position the patient in an infinite number of positions. **(FIG.2)**

NOTE: The attendant must also squeeze the handle to allow the patient to be brought back to the standard sitting position before the patient can get out of the chair safely.

12. The chair can be changed from the Attendant positioning to User Controlled positioning. This means that the Release Handle must be relocated underneath the left Upholstered Armrest (the instructions on the following pages will describe how you can make this change to your chair). Once this change is made, the User can control their own recline position by squeezing the handle under the left Upholstered Arm of the chair. **(FIG.1)**

NOTE: The attendant can still operate the chair; however, leverage to move the patient will not be as effective as with the Attendant Controlled positioning option.



*Stay clear of recline mechanism.
Periodically recheck tightness of ALL screws & bolts, & never use the tray as a restraint.*

Maintenance of the Chair

13. To ensure proper operation of the reclining mechanism, lubricate all pivot points with a silicone lubricant at least twice yearly.
14. The back cushion can be replaced by opening the “Hook & Loop” flap on the lower rear of the back cushion, removing the Push Handle, and sliding it off of the **Back Frame**. **(FIG.3)**
15. The seat/legrest cushion can be replaced by removing the (2) seat hold-down slat screws (attaching the underside-rear of the seat cushion to the chair frame) then slide the cushion off toward front of chair.



Optional 5-inch Caster Placement

16. The casters on this 5351-5361 chair, can be configured one of two ways; Rigid casters in front & Total Lock casters on rear or vice versa.

If you wish your chair to have casters in opposite configuration, please follow below instructions.

- Lay chair on side on carpeted surface. Use a Phillips screwdriver and 7/16" wrench to remove the 1/4" bolt & nut from chair legs.
- Remove bolts and casters. **IMPORTANT:** Be sure to also remove the plastic Caster Insert Sleeve from chair leg. This piece must be repositioned so that the bolts line up with slot on Insert Sleeve when caster is re-inserted into chair leg.
- Re-insert casters into chair legs. (Follow **IMPORTANT** note in above step)
- Insert bolts and nuts; tighten all with screwdriver and wrench.



Wrinkles in Vinyl – Storage and shipping can cause wrinkles of the vinyl on your Winco chair. This is normal. Please allow 1-2 weeks at room temperature (approx. 70 degrees) to allow for vinyl to expand back to original appearance.



Optional Release Handle Mounting location:

Tools Needed: Phillips Screwdriver & Flat Screwdriver

- Use Phillips screwdriver & remove the Release Lever and screw from the Push Handle.
- Use Phillips screwdriver & remove the rear screw that attaches rear of left Side Panel.
- Use flat screwdriver & remove left Armrest, and then insert the included flat-head screw into hole with countersink located on metal arm plate.
- Route the Release Lever between the Side Panel and Frame as shown in photo above.
- Use flat screwdriver & thread flat-head screw into the Release Lever and tighten.
- Re-install Armrest.
- Re-attach rear of Side Panel.
- Install the included plastic "Split-Stem Cap" in the empty hole on the Push Handle.



Visit our website www.wincomfg.com/product-documents/parts-lists for a complete parts list catalog of your chair or call Customer Service @ 1-800-237-3377 to request it by mail.



LIMITED WARRANTY

• 5516 SW 1st Lane • Ocala, FL 34474
 • Phone (352) 854-2929 • (800) 237-3377
 • Fax (352) 854-9544
 • www.wincomfg.com
 • customerservice@wincomfg.com

TERMS

Winco Mfg., LLC. warrants this product to be free of manufacturer's defects in material and workmanship, provided that the product is used according to normal operating conditions and proper maintenance intended by manufacturer. This warranty is available only to the original retail purchaser, is non-transferable and commences on the date of retail sale; proof of purchase required.

Limited One Year Complete Product Warranty: Winco Mfg., LLC warrants the complete product for one (1) year. At Winco Mfg., LLC. sole discretion, it may repair or replace any components freight free that are found to be defective during the first year. Winco Mfg., LLC. shall not be liable for any labor, or any other costs incurred as a result of or in conjunction with a warranty claim.

Limited Three Year Warranty: Winco Mfg., LLC warrants the recliner mechanisms, electrical components, vinyl [from cracking or delaminating] pressurized gas springs, when new, for a period of three (3) years. At Winco Mfg., LLC. sole discretion, it may repair or replace components found to be defective. Winco Mfg., LLC. shall not be liable for any labor, shipping or any other costs incurred as a result of or in conjunction with a warranty claim.

Limited Lifetime Chair Frame Warranty: Winco Mfg., LLC warrants the steel chair frame, when new, for the lifetime of the original purchaser. This limited warranty does not apply to paint/finish or any components attached to the frame such as; upholstery, foam, casters, mechanisms or related parts that are covered under above warranties. Winco Mfg., LLC shall not be liable for any labor, shipping or any other costs incurred as a result of or in conjunction with a warranty claim.

The purchaser's exclusive remedy under this warranty shall be limited to such repair or replacement of defective components at Winco Mfg., LLC sole discretion. For warranty service, contact the dealer that the product was originally purchased from or Winco Mfg., LLC directly.

EXCLUSIONS

There are no other warranties, conditions, representations or guarantees, express or implied, made or intended by Winco Mfg., LLC and all other warranties, conditions, representations or guarantees including any warranties, conditions, representations or guarantees under any Sale of Good Act or Like legislation or statute is hereby expressly excluded. Any and all other implied warranties shall not extend beyond the duration of the express warranty. Liability for incidental or consequential damages is excluded to the extent permitted by law. Some states do not allow the exclusion or limitation so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights. In addition you may also have other rights, which vary from state to state.

GENERAL PROVISIONS

No warranty herein contained or set out shall apply when damage or repair is caused by any of the following:

1. Damage in transit.
2. Accident, alteration, abuse or misuse of product ie. exceeding weight capacities, applying inordinate pressure to footrest/leg rest, use in Mental Health facilities or like institutions.
3. Fire, water damage, theft, war, riot, hostility, acts of God.

Examples contained in this list are not to be construed as all-inclusive.

