

# OAKWORKS® Table Cart



Fig. 1

Thank you for purchasing an OAKWORKS® table cart. Your new cart is designed to give you years of trouble-free service and easy maintenance. It arrives folded, with the tie-down strap wrapped around the handle and buckled in place. Just follow the steps below to get you and your table underway.

## To Set-up:

- Release the buckle on the tie-down strap. Unwrap the strap from around the handle and unfold the cart allowing the floor of the cart to drop into its horizontal position, and the padded handle to stand upright. (Fig. 1)
- Lift your table by its handles and set it (with rubber feet down) on the nylon sling of the cart floor. The table should be close to, or touching, the “foot end” of the base opposite the wheels. (Fig. 2)
- Make sure that the part of the strap that spans the handle lies across the table’s top corner and buckle the two ends of the tie-down strap together. (Fig. 3) Now pull the end of the strap to tighten it so that the table is pushed up to the “foot end” and the cart holds your table snugly. (Fig. 2a)
- Brace your foot against the axle and pull down on the handle until you feel the weight of the table balanced between the wheels and the handle. (Fig. 4)
- Clasp the handle and pull the cart and your table will follow you anywhere. (Fig. 5)



Fig. 2



Fig. 3



Fig. 3a



Fig. 4

## Easy Maintenance:

- Your new OAKWORKS® table cart has a tough powder coated finish that is waterproof and rust resistant. The nylon slings and the tie-down strap are also extremely durable and easy to care for. All parts of your cart can be washed with soap and water and air dried.
- To lubricate the wheels, use any standard machine oil or silicone spray. We do not recommend rubbing metal parts against concrete or stone steps as this will cause excessive wear.

## Warranty:

OAKWORKS® guarantee this table cart to the original owner for a period of one year. This warranty cover defects in labor and materials and is limited to repair or replacement of the item at our discretion. It does not cover damages caused by accident, misuse and normal wear or neglect. OAKWORKS® will cover UPS Ground shipping charges within the continental U.S. for all warranty work. Customers must call before shipping a product back to OAKWORKS®. For warranty service contact Customer Service at 1-800-558-8850.



Fig. 5

**OAKWORKS®, Inc.**

923 East Wellspring Rd., New Freedom, PA 17349

Toll Free Phone: 800-558-8850

Toll Free FAX: 877-562-4787

[www.oakworks.com](http://www.oakworks.com)

Phone: 717-235-6807

FAX: 717-235-6798

